

**FMC Check**

- **Ident**
- **POS – Check UTC time**
- **Route**
- **Perf – Enter Step Size**
- **Thrust limit**
- **T/O page 2 (Noise abatement restrictions)**  
**( Enter Wind in to check crosswind component)**
- **Legs**

**Departure...{Check against PLAN mode}**

**Wind**

- **Nav Rad**
- **Prog (Check ground distance)**
- **Route 2 Copy**
- **Fix**

**Resting Page PERF INIT**